







We open the strap of the side and we introduce the Foam. The rounded part has to be on the top and in the zip side (fig 01).



After inserting the foam, we insert the paperboard with the rounded parts down in the same pocket than the foam on the inner side part of the bag (fig 02).